

Classic Brass

Fine Solid Brass Decorative Hardware

P.O. Box 3563
Jamestown, New York 14702-3563
(800) 869-3173
Fax: (800) 215-2019
E-mail: sales@classic-brass.com

Half Dummy Knob & Rosette Installation Instructions

PREPARE THE DOOR:

1. Determine the desired position of the knob on the door and mark. Drill a 3/4" diameter bore hole approximately 1/4" deep. This bore hole is meant to accommodate the back of the dummy mounting plate.

Do Not drill all the way through the door for this application!

Prior to installation, test fit this plate to assure that it sits flush against the door surface. It may be necessary to expand the bore hole in the door.

INSTALLING THE HARDWARE:

2. Using a square on the door edge, position the dummy rosette mounting plates as shown, with the flat portion perpendicular to the edge of the door.

3. With the dummy mounting plate in place, mark the center location of the three screw holes. Drill three 1/16" pilot holes in the door for the screws.

Attach the mounting plate to the door using the three #5 x 1" screws provided.

4. Position the rosette over the spindle. Insert the threaded hub into the center hole of the rosette and screw it into the mounting plate. Tighten the hub with the rosette hub key provided.

Note: Square and rectangular rosettes will only fit on the mounting plate when properly oriented. Rotate the plate as necessary to fit over the mounting plate.

5. Slide the knob over the end of the spindle and seat it against the hub. Secure it with the set screw using the 1/8" Allen wrench provided.

BILL OF MATERIAL:

- (1) Knob
Includes:
- (1) 1/4-28 set screw
- (1) Dummy rosette mounting plate assembly.
Includes:
- (1) Mounting plate
- (1) Threaded hub
- (1) 1-3/8" x 8mm spindle - pre-mounted
- (3) #5 x 1" FHWS
- (1) Rosette
- (1) Rosette hub key
- (1) 1/8" Allen wrench

